

ROLLEX MEDICAL NZ LTD

38E Highbrook Drive, East Tamaki, Auckland 2013, New Zealand
 PO Box 204159, Highbrook, Auckland 2161, New Zealand
 Phone: +64 9 274 0707 Fax: +64 9 274 0709
 Email: sales@rollexmedical.co.nz www.rollexmedical.co.nz

The MATOS® Aria Eco fridge series is a new range of cost-effective European-built Medical and Vaccination Refrigerators featuring the latest technology in controllers and compressors for accurate temperature stability.

Model Variations

- MATOS Aria Eco 300 R – Solid Door
- MATOS Aria Eco 300 R/G – Glass Door



MATOS Aria Eco 300 R

Advanced Controller

Featuring the Carel soft touch controller - accurate to 0.1°C with min/max readings at the touch of a button.

Lock Fitted as Standard

Maintains security and ensures the unit can only be opened by an authorised personnel.

Cost-Effective

Built with a High Impact Polystyrene Interior to provide a robust and in-expensive range of refrigerators.

Solid or Glass Door Options

Solid or glass door options enabling you to select the format which best suits your requirements. Glass doors are double glazed, toughened safety-glass with argon gas between panels for better insulation.

Auto Defrost

The advanced controller initialises a regular defrost sequence to decrease the chance of ice build-up while maintaining the temperature below 8°C.

Extended Warranty

Standard 12 month warranty however an extended warranty option is available subject to Terms and Conditions

Specifications

Capacity	269L Net / 290L Gross	Power usage	Solid 2.9kW Glass 3.6 kW / 24 hours
Dimensions external	597w x 645d x 1700h	Air convection	Fan assisted
Dimensions internal	505w x 462d x 1355h	Operating range	1°C to +10°C
Door	Solid and Glass available Reversible	Controller	Microprocessor with external LCD graphic display
Weight	Solid 65kg / Glass 74kg	Interior/Exterior	(HIPS) High impact polystyrene
Shelves fitted	6	Temperature resolution	0.1°C
Castors	2 wheels rear, 2 adjustable feet front	Temperature fluctuation at 4°C	+/- 0.5°C
Internal light	Yes	Refrigerant	R134A
Door Open Alarm	Yes	Power	230V / 50Hz